



FILE FOR

RAPID PROTO

- SUPPRESS

HOLES

- ADD .5mm

MACH STICK

ON PLUG BUSSES

